# STATUS LED EXPLAINED
## ON SIGN CONTROLLER

Different LED colours represent different statuses as explained in the table below.

| | Second 1 | Second 2 | Second 3 | Second 4 | Second 5 |
|---|---|---|---|---|---|
| **Initialising on Startup** <br> Approximately 3 minutes | On for approx. 4 seconds. | | | | |
| **SIM Card OK** | 🟢 | 🟢 | 🟢 | 🟢 | |
| **SIM Card Error or No SIM** <br> Check SIM card | On for approx. 2 seconds. | | 🔴 | 🔴 | |
| **Modem Fail or No Network** <br> Check aerial and/or controller | On for approx. 4 seconds. | | | | |
| **Active Internet Session** | 🟣 | 🟣 | 🟣 | 🟣 | |

**LAST FLASH**

🟢 **All OK**

🔴 **Low Voltage**

🔵 **Tamper Alarm**

⚪ **SD Card Error**

**Location of Sign Controller:** Middle/right inside the Sign Head.